CALIBRATION OF SCALES

- MARINE M1100 SCALES CALIBRATION SHOULD ALWAYS BE DONE WHEN AT SEA FOR BEST RESULTS.
- TURN POWER ON THE SCALE AND LET IT WARM UP FOR AT LEAST 10 MINUTES.
- PRESS MENU (IN THE RIGHT TOP CORNER) AND ZERO (IN THE LEFT BOTTOM CORNER), BOTH AT SAME TIME.
- NOW YOU WILL SEE “CAL” IN THE LOWER DIGITAL WINDOW.
- WAIT UNTIL THE MESSAGE IN THE TOP WINDOW SAYS “PUT 5KG WEIGHT ON” THEN PLACE THE WEIGHT ON SCALE (YOU MIGHT BE REQUESTED TO PUT 2 -3 or 5 KG).
- ONCE THE REQUESTED WEIGHT COMES IN THE TOP WINDOW PRESS “PRINT” ON THE RIGHT SIDE.
- YOUR CALIBRATION IS NOW DONE.
- TEST THE SCALE WITH THE WEIGHTS AGAIN ONE AT A TIME.
- USE CALIBRATED WEIGHTS ONLY TO GET THE BEST OUT OF YOUR SCALE.
- CALIBRATING THE SCALES TAKES ONLY 2 MINUTES BUT CAN SAVE THOUSUNDS OF DOLLARS. WE RECOMMEND WEEKLY CALIBRATION.
- POWER SURGE PROTECTOR IS RECOMMENDED FOR THE SCALES.